


## **CASTER WHEEL KIT**


FS STORAGE RACK SYSTEM

## Installation & Loading Instructions - Please Read Before Beginning Veuillez lire les instructions avant d'entreprendre l'installation et le chargement




. Remove the four outside Levelers located on the bottom of the Frame Legs. See image 1.

NOTE: If this is a new installation, skip Step 1 and go directly to Step 2.



. Align and screw the caster into the threaded nut on the outside bottom of the Frame Leg. Repeat for the other three casters. See image 2.



. To lock the caster into a fixed position, press down on the plastic tab. To release, pull up. See image 4.



a washer and lock nut to the exposed threaded end. Firmly tighten. Repeat for the other three casters. See image 3.